


## Assembly Instructions for using the **LC120 Height Setter**



Position **Bolts** loosely on all the **Legs** leaving enough room for the **Rails** to fit.



Place 1st outer Rail into correct position on 2 sets of Legs.



Place **LC120 Height Setter** under middle of the **Rail** to keep a constant height.



Tighten **Bolts** with the **Rail** in place at the correct height.

Once the first Rail is in place, the above instructions need to be repeated on the other 5 Rails in order to get the frame at a constant height. Then its just a case of attaching the Rail Arms to the fitted Rails and placing the relevant tops onto the framework. The LC120 Height Setter can either be discarded or stored away for future use.













