

Range

Pedestals DMSF/N/F and DMSF/F

Guide

Replacement Lock



Please Follow
These Instructions



1 Lock the pedestal



1. Check the pedestal is locked.

If not already locked, use a blue master key to lock the pedestal.

2 Remove inner barrel



2. Insert the red barrel changer key into the lock opening and turn anti-clockwise.

Keeping pressure applied to the left, pull the key out. The barrel insert should withdraw from the opening with the key.

Discard of the old barrel by pulling it off the key.

3 Insert new barrel



3. Insert the red key into the new barrel and place into the pedestal. When inserted, turn the key clockwise.

Keeping pressure applied to the right, pull the key out.

(If the barrel does not stay in place, repeat this step applying more pressure, and use your finger to hold the barrel in place while the key is pulled out.)

4 Insert new key



4. Insert the new black key that was supplied with the barrel. They will both feature the same reference number.

This key can now be used to open and lock the pedestal.